



LOCK GUARD SERIES 1625-1627

1. Before applying the Lock Guard, be sure that it does not interfere with the outside door plate or with the inside frame door stop.
2. Place the Template on the door with offset centered over the lock face. Have the Template overlap the door frame sufficiently to protect the lock strike. Secure the Template to the door with tape.
3. Mark four spots at "C".
4. Drill four holes through the door at "C" using a 9/32" drill. On the outside of the door, enlarge the 9/32" holes with a 7/16" drill.
5. Place the Lock Guard on the door, attach with machine screws and tighten securely. If necessary use shim for greater clearance at the lip of the strike.

Template	Date:	Revision
02194-11-000	08-15-05	B



Precision Hardware

A Division of Stanley Security Solutions, Inc.
www.stanleysecuritysolutions.com

TYPICAL FRAME AND DOOR DETAIL

